

## VI.5.3D-FREEDATE PROGRAM FCST HCL TECHNIQUE FREEDATE

### Purpose

Technique FREEDATE sets the date of carryover to be freed.

Valid values are NO (0) and YES (1).

The Global default is NO (0).

This Technique is Universal.

This Technique has one Argument which is the date of carryover to be freed.

The Global default for the date is January 1, 1900 at 12Z.

### Form of Input

FREEDATE date

where date is the date of carryover to be freed

### Examples

FREEDATE 062682

The date to be freed will be June 26, 1982.

FREEDATE \*-31

The date to be freed will be 31 days before TODAY.